

These are the base parts for the adjustable series mounts. Please follow the guide below to successfully remix.

- Zip folder includes one normal piece and one beefy piece to help against breakage on bando style builds.
- Create one side first, then mirror for other side.
- Pieces must be 12mm apart for the mount to fit properly.
- Approximate height of these pieces must be 4mm from top plate for proper gear space.
- In most cases, you will need to punch vertical holes into the frame kit base pieces aligned with the top plate bolts and horizontal holes through the frame kit base pieces.
- We have found it's best to make your frame kit base part 9mm tall and mesh these adjustable pieces 5mm into the base pieces vertically.
- If you have any questions, feel free to email us and we will do our best to help you.